


















Priority Command

Intersection Receiver DIP Switch Settings

Intersection Size DIP 1, Switches 1–4		Speed Limit DIP 1, Switches 5–7		Yellow Light Time DIP 2, Switches 4–7	
Intersection Size (feet)	Switch Setting	Speed Limit (mph)	Switch Setting	Yellow Light Time (sec.)	Switch Setting
30	0	25	0	4	0
45	1	30	1	5	1
60	2	35	2	6	2
75	3	40	3	7	3
90	4	45	4	8	4
105	5	50	5	9	5
120	6	55	6	10	6
135	7	60	7	11	7
150	8	<p>NOTES: Intersection Size must be set before setting the intersection location and cannot be changed without relocating the intersection.</p> <p>Speed Limit sets the fixed offset distance and may be adjusted at any time before or after the receiver is calibrated. Each increment is ~15 feet.</p> <p>Yellow Light Time may be adjusted at any time before or after the receiver is calibrated.</p>	12	8	
165	9		13	9	
180	10		14	10	
195	11		15	11	
210	12		16	12	
225	13		17	13	
240	14		18	14	
255	15		19	15	

Low-Priority DIP 2, Switch 1 OFF  ON 	Around-the-Corner Mode DIP 2, Switches 2 & 3 Never   Conditional   Always  
--	--

Key to DIP Switch Settings

	0	1	2	3	4	5	6	7
ON 								
OFF 