Priority Command

RX-1
Intersection

Receiver

- 1. Connect antenna, preemption outputs, and power.
- 2. Set DIP switches according to the tables below.
- 3. Push and hold button for 2 seconds until the LED starts to flash.
- 4. Position vehicle in center of intersection and activate transmitter. LED will blink 10 times quickly and return to solid green.

